



Lab.

Objectives and tools

- To implement
 - Hello world
 - Out
 - Inout
 - a FIR filter
 - an IIR filteron the C6748 LCDK
- Tools:
 - C6748 LCDK
 - CCStudio 5.3.0 on a PC with Windows
 - function generator
 - oscilloscope
 - projects (already prepared by the teacher)

Function (or signal) generator

- Normally, floating
- Main controls
 - wave shape (sine, triangular...)
 - amplitude
 - frequency



Oscilloscope

- Normally grounded
- “Crocodile” tip is common, grounded; probe tip is the input
- Main controls:
 - horizontal scale (time/div.)
 - vertical scale (V/div.)
 - coupling (AC/DC)
 - trigger source
 - several trigger options (put mode to “auto”)



Some notes

- *Pay attention to possible electrostatic discharges, especially in dry days*
 - grip the PCB (printed circuit board) along its borders
 - don't touch the electronic components
 - don't touch the copper lines of the PCB
- The left channel in the jack connectors should be the red wire, but please check

S/W installation

- Method 1:
 - Copy the TI DVD on the hard disk
 - Install CCS from the hard disk
 - using *ccslicense* for the activation
 - copy the *ccslicense.lic* file in c:\Program Files\ti
 - in c:\Program Files\ti (or c:\Programmi\ti)
 - C6000, C6748, XDS100
- Method 2:
 - Download version 5.3 from http://software-dl.ti.com/ccs/esd/documents/ccs_downloads.html
 - follow instructions for the activation
 - in c:\Program Files\ti (or c:\Programmi\ti)
 - C6000, C6748, XDS100
- Then
 - Copy the *assets* folder in c:\Program Files\ti
 - Copy the *projects_basic* folder on the desktop

Starting CCS

- Connect the LCDK to the PC using the XDS100v2
 - dip switch: all off, i.e. towards the jack connector
- For *inout* and *fir_filter*: line in at the top, line out at the bottom
- Open CCS
- *File... new... target configuration file... file name:*
nameNewTargetConfiguration.ccxml,
 - set *use shared location* (or not?)
 - emulator: *xds100v2*
 - *LCDK6748*
- Save

Loading, compiling and running projects

- *View/project_explorer*
- *project... import existing CCS eclipse project...*
- it may be necessary to correct
 - the user name in the *.project* file of each project
 - the path for the *include* in “assets”
 - show build settings... C6000 compiler... include options
 - the path for the *lib* in “assets”
 - show build settings... C6000 linker... file search path
- in *file/properties*, or in *project properties*
 - build.. c6000 compiler
 - optimization
 - advanced options / assembler options: keep asm files
 - the asm can be found in the Debug folder
- (in edit mode) *build*
- *debug* (moves to debug mode)

Our interrupts

The 6748 has 128 interrupt sources, but room for only 16 ISRs (interrupt service routines)

- 12 interrupts can be programmed [tms320c6748.pdf, p. 92]
- interrupts 0 to 3 are RESET, NMI and 2 reserved

For our interrupt:

- MCASP0 (multichannel audio serial port 0) generates the event EVT 61 [tms320c6748.pdf, p. 93]
- 61 (i.e. 0x3d) is written in the low part of the register INTMUX1 [L138_LCDK_aic3106_init.c, line 655]
- the low part of the register INTMUX1 is associated with the interrupt INT4 [L138_LCDK_aic3106_init.c, line 653, and sprufk5a.pdf, p. 178]
- the routine associated with INT4 (its code is in main.c) is *interrupt 4* [vector_intr.asm, line 48]

Designing simple filters with Matlab

- For e.g. a FIR passband filter
 - `b=fir1(15, [0.2 0.3]);`
 - `freqz(b);`
 - `zplane(b);`
- For e.g. an IIR passband filter
 - `[b,a]=butter(15, [0.2 0.3]);`
 - `freqz(b,a);`
 - `zplane(b,a);`